



[Knowledgebase](#) > [Smartwatches](#) > [Reebok Pulse Troubleshooting and Information](#) > [Product Features](#) > [Changing the Watch Face on Your Reebok Pulse](#)

Changing the Watch Face on Your Reebok Pulse

Inas B. - 2025-08-20 - [Product Features](#)

Your watch face is your style, and switching it up is easy. Whether you want something sleek, sporty, or info-packed, here's how to customize your Reebok Pulse's look in just a few taps.

On the Watch

- **Touch and Hold:** Press and hold the current watch face until you enter edit mode.
- **Swipe Left or Right:** Browse through available styles.
- **Tap:** Select the watch face you want to use.

Through Settings

1. From the watch face, **swipe down** to open quick settings.
2. Tap the **settings icon** (gear).
3. Select **Display**, then **Watch Face**.
4. Swipe through options and tap to apply your favorite.

Using the App

For even more watch faces and customization:

1. Open the **app** on your phone.
2. Tap **My Watch** at the home screen menu.
3. Select **Watch Face Settings**.
4. Browse additional watch faces available for download and apply the ones that fit your vibe.

Switch up your look anytime to match your mood, activity, or style, because your

Reebok Pulse should work as hard as you do.