How to Use Theatre Mode on Your Reebok Stride

Inas B. - 2026-11-02 - Product Features

Theatre Mode reduces screen activity when you do not want the watch to light up or respond to wrist movements.

When Theatre Mode is enabled:

- The screen is dimmed.
- **Wake by Wrist Up** is disabled.

This feature is useful in dark or quiet environments where you want to minimize screen distractions.

To return to normal operation, disable Theatre Mode.