What Is Silent Recording on My Reebok Kinetic?

Inas B. - 2026-11-20 - Health & Activity Tracking

Silent Recording is an activity setting that enables Do Not Disturb for the duration of a workout.

When enabled, it helps prevent incoming notifications from interrupting your training session.

You can configure Silent Recording from the activity settings before starting your workout.

The setting applies for the duration of the activity. Once your workout is finished, your usual notification preferences can resume.