How to Use Power Saving Mode on Your Reebok Stride

Inas B. - 2026-11-04 - Charging & Battery

Power Saving Mode helps extend your watch's battery life by limiting the information displayed on the screen.

When Power Saving Mode is enabled, the display shows:

- Time
- Steps
- Battery level

Exit Power Saving Mode

Press and hold the **top button for 5 seconds** to exit Power Saving Mode.