How Do Calls, Quick Replies, and Notifications Work on My Reebok Kinetic?

Inas B. - 2026-11-17 - Features & Settings

Your Reebok smartwatch lets you manage certain calls and notifications directly from your wrist. Available actions depend on your watch model and connected phone.

Managing Incoming Calls

When you receive an incoming call, you can use your watch to ignore or hang up the call.

You cannot answer calls directly from the watch because it does not have a built-in speaker or microphone.

Quick Replies (Android)

On supported Android phones, you can respond to messages using quick replies. These may include preset responses or customized replies, depending on the available options.

Syncing and Clearing Notifications

On supported models, notification dismissal is synchronized between your watch and phone. Dismissing a notification on either device clears it from both.

Some alerts are managed separately:

- **Alarms and watch alerts:** Alarms and alerts created directly on your watch remain on the watch and must be dismissed there.
- **Individual notifications:** Open a notification and dismiss it from its detail view.
- **Clear all notifications:** Scroll to the bottom of the notification list and select the option to clear all notifications.