



[Knowledgebase](#) > [Smartwatches](#) > [Reebok Icon Troubleshooting and Information](#) > [Product Features](#) > [Music Control: Your Remote Soundtrack](#)

Music Control: Your Remote Soundtrack

Inas B. - 2025-08-20 - [Product Features](#)

The beat doesn't stop just because your phone's in your pocket. With the Reebok Icon, control your music right from your wrists; no need to reach for your phone mid-workout or mid-stride.

Play, Pause, Skip

- Control your favorite music app directly from your Reebok Icon:
- Play / Pause your tracks
- Skip to the next song

Don't See the Music Widget?

If the music controls aren't showing:

- Make sure music is playing on your phone
- Check that Bluetooth is enabled and your phone is connected to the watch

If there's no music active on your phone, the widget won't appear.