



[Knowledgebase](#) > [Smartwatches](#) > [Reebok Rush Troubleshooting and Information](#) > [Troubleshooting & Performance](#) > [Recovering Your Reebok Rush After a Forgotten PIN](#)

Recovering Your Reebok Rush After a Forgotten PIN

Inas B. - 2026-09-21 - [Troubleshooting & Performance](#)

If you forget your PIN:

- Entering an incorrect PIN 5 times will trigger a factory reset.
- The factory reset erases all data stored on the watch and restores it to its original settings.
- After the reset, you must pair the watch with your smartphone again.