



[Knowledgebase](#) > [Smartwatches](#) > [Reebok Icon Troubleshooting and Information](#) > [Product Features](#) > [Weather: Your Forecast at a Glance](#)

Weather: Your Forecast at a Glance

Inas B. - 2025-08-20 - [Product Features](#)

Plan smarter. Move with the moment.

With real-time weather updates delivered straight to your wrist, the Reebok Icon makes it easy to check the skies, with no need to pull out your phone.

Current Conditions

From your morning run to your evening wind-down, your Reebok Icon keeps you updated with:

- **Temperature**
- **Feels-like temperature**
- **Simple weather descriptors (e.g., sunny, cloudy, rainy)**

All at a glance, just swipe to check your forecast.

Location Matters

To serve up local conditions, the Reebok Icon needs a few things working together:

- **Connected Phone:** Your watch receives forecast data from your smartphone.
- **Internet Access:** Your phone must have an active internet connection to retrieve weather data.
- **Location Permissions:** Make sure the app has permission to access your phone's location. You can check and update this in your phone's settings.

About the Data Source

Reebok Icon pulls its forecast information from OpenWeatherMap, a globally trusted weather data provider. Forecasts may vary slightly from other platforms (like AccuWeather or Weather.com) due to differences in data models, update frequency, or satellite inputs.

If you're seeing a slight difference across apps, that's normal. What matters is consistency, and OpenWeatherMap delivers that.

Tips for Reliable Weather Updates

- Check app permissions regularly, especially after software updates.
- Keep Bluetooth and location services enabled on your phone.

- Allow background data access for the app so it can sync forecasts automatically.