



[Base de connaissances](#) > [Montres Connectées](#) > [Dépannage et Informations - Reebok Rush](#) > [Dépannage & Performance](#) > [Troubleshooting Weather Sync on Your Reebok Rush](#)

Troubleshooting Weather Sync on Your Reebok Rush

Inas B. - 2026-10-23 - [Dépannage & Performance](#)

If weather information is not updating:

- Make sure your watch is connected to your smartphone.
- Make sure your smartphone has an active internet connection.
- Check your smartphone settings to make sure the Reebok Connect app has permission to access your location.
- Open the Reebok Connect app and allow the watch to sync with your phone.